



Underlayment with Vapor Barrier

Base para piso con barrera contra el vapor

STEP 1:

Calculate and purchase enough underlayment to allow your flooring install to float over the subfloor, providing support for your home's flooring upgrade.

STEP 2:

Prepare the subfloor. Make sure it is solid and clean. Repair any damaged sections, make sure it is clean and free of debris. Please follow flooring manufacturers detailed instruction for subfloor preparation.

STEP 3:

Start in the corner of the room and roll out the underlayment and cut at the far end of the room.

STEP 4:

Seams should be butted together, leaving no gaps or overlaps.

STEP 5:

Repeat step 3 with the cut edge of the roll laid over the extended/film adhesive strip.

STEP 6:

Fold the cut edge of the foam roll up and peel off the adhesive strip release liner. Release the foam edge allowing it to lie over the adhesive strip. Apply slight pressure to secure a solid bond between the two edges.

STEP 7:

Cut as needed to fill the geometry of the room, allowing for door transoms with extra material to be cut away after flooring is laid. Your underlayment is now ready for flooring install.

PASO 1:

Calcula y compra base para piso suficiente que permita a la instalación del piso flotar sobre el contrapiso y proveer así soporte para mejorar el piso de tu hogar.

PASO 2:

Prepara el contrapiso. Comprueba que esté sólido y limpio. Repara todas las secciones dañadas; asegura que esté limpio y sin residuos. Sigue las instrucciones detalladas del fabricante del piso para preparar el contrapiso.

PASO 3:

Comienza por la esquina de la habitación, desenrolla la base para piso y corta en el extremo lejano de la habitación.

PASO 4:

Las juntas deben unirse bien sin dejar espacios ni superposiciones.

PASO 5:

Repite el paso 3 con el borde cortado del rollo tendido sobre la tira adhesiva de película/extendida.

PASO 6:

Dobla el borde cortado del rollo de espuma hacia arriba y desprende el papel adherente de la tira adhesiva. Suelta el borde de espuma apoyándolo sobre la tira adhesiva. Presiona ligeramente para asegurar que los dos bordes queden bien pegados.

PASO 7:

Corta según sea necesario para ajustar a la geometría de la habitación y deja material extra en los montantes de la puerta para cortarlo después de tender el piso. Ya tu base de piso está lista para instalar el piso.