


USE AND CARE GUIDE

Husky Professional Duty 63.5 in. Top Locker

Questions, problems, missing parts?
Before returning to the store, call
Husky Customer Service
8 a.m – 7 p.m., EST, Monday-Friday
9 a.m – 6 p.m., EST, Saturday

1-888-HD-HUSKY

HUSKYTOOLS.COM



THANK YOU

Table of Contents

Table of Contents	2
Safety Information	2
Warranty	3
Specifications	3
Package Contents	3
Hardware Included	

Assembly	. 5
Maintenance	. 7
Replacement Parts	.8

Safety Information

- To reduce the risk of injury, please read and follow the safety instructions below before assembling and using this product.
- 2. Two or more people are required for the assembly of this product.
- Secure this product properly before moving it with a forklift.
- 4. Do not tow the product with power equipment.
- Do not alter this product in any manner. For example, do not weld external lock bars or attach electrical equipment.
- Before locking the cabinet, ensure there are no obstructions in order for the door to completely close and lock bars to work properly.



CAUTION: Keep the product on level surfaces. The product may become unstable and tip if stored or moved on an unlevel surface, which may cause personal injury or product damage.



CAUTION: Lock the door before moving this product. The door could come open and make the product unstable, which may cause personal or product damage.



CAUTION: Do not attach or mount this product to a vehicle or mobile trailers. This may cause personal injury or product damage. Mounting this product to any vehicle or mobile trailers in any manner will void warranty.



CAUTION: Do not stand, sit or climb on this product. You may fall which may cause personal injury or product damage.

!Save these instructions.



Warranty

This Husky Professional Grade product includes a Limited Lifetime Warranty, whereas the manufacturer warrants the product to be free from defects in materials and workmanship for the product's useful life. If any part of this product is found to be defective, the manufacturer's only obligation, and purchaser's exclusive remedy, is to provide replacement parts at the manufacturer's discretion, provided that the product has not been damaged through misuse, accident, modifications, alterations, neglect or mishandling.

This warranty shall not apply to any product that is found to have been improperly installed, setup, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to normal wear and tear or lack of maintenance, or a failure of the product as a result of use in a highly corrosive environment, improper storage, misuse, abuse, negligence, alteration, faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product such as surface and/or weathering, as this is considered normal wear and tear.

The manufacturer does not warrant and specifically disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacture specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of said product.

Contact the Customer Service Team at 1-888-HD-HUSKY or visit www.huskytools.com.

Specifications

Maximum Load Capacity	2,000 lbs
-----------------------	-----------

Package Contents

HARDWARE INCLUDED



NOTE: Begin product assembly close to the final intended location of your cabinet. The product is heavy and may be difficult to move after assembly.



NOTE: Hardware not shown to actual size.
















Part	Description	Quantity
AA	Hexagon head flat bolt (M8*60mm)	8
BB	Washer	8
СС	Hex socket button cap bolt	4
DD	Hex key	1
EE	EVA Spacer	2
FF	Plastic plug (M6)	16
GG	Plastic plug (ø15mm)	8

Package Contents (continued)



NOTE: Keys are attached to gas strut.



Part	Description	Quantity
Α	Top Locker	2
В	Handle	2
С	Magnetic Husky® logo badge	2

Assembly

This Husky 63.5 in. Top Locker is designed as a set and only intended to be used with the Husky Professional Duty system, which includes the following products:

72 in. 20-Dr. Professional Duty Workbench M 72 in. Professional Duty Hutch M

Model#HPRO72MWC20BLK Model # HPRO72HUTCHBLK Model # HPRO27SLOCKERBLK SKU#100000 SKU # 1000000000 SKU # 1000000000




CAUTION: Two people are required for assembly.

1 Setting the Top Locker

27.5 in. Professional Duty Side Locker

- □ Attach both side handles using 8 pcs Bolts (BB) and tighten with supplied Hex Key (CC).
- Peel off the paper back from the 2 EVA Spacers (EE), and affix in the appropriate position toward the rear of the Top Locker (A).
- Gently place the Top Locker to the top left side of the existing Hutch and Side Locker.






NOTE: Husky Professional 27.5 in. Side Lockers are required on both sides of the 72 in. Workbench and Hutch in order for the 63.5 in Top Locker installation.


2 Attach the Top Lockers to the Hutch & Workbench.

- Open the Top Locker door.
- □ Attach the Top Locker (A) using 4 pcs M8*60 flat bolts (AA) and 4 pcs washers (BB) with supplied Hex Key (DD) in the 4 corners.
- □ Do not tighten bolts until both lockers are attached and flush.
- □ Remove the 2 Side handles (B) from the Top Locker (A) and repeat Step 1 and 2 for the 2nd Top Locker installation.




- □ Once both Top Lockers are attached and the front and top edges are flush with the existing Hutch and Side Lockers, then tighten all 8 bolts (AA). Be careful not to overtighten.
- ☐ The Husky® Logo badge (C) is magnetic and can be moved to either side of the Top Locker.
- □ If desired, the 2 Side Handles (B) can be attached to the ends of the Top Lockers, or removed.





3 Remove the plastic plug (Optional)

□ Remove the 16 plastic plugs (FF) and 8 plastic plugs (GG) from the top locker side panels and top panel if needed.



4 Kwikset Smartkey® Lock Operation

- □ This product has been equipped with the Kwikset Smartkey® locks which allow you to easily program each lock cylinder to a specific key code to match other Kwikset keyed products.
- □ Please Kwikset Smartkey® see supplemental instructions for keying and re-keying the locks.


Maintenance

- Periodically clean the door fronts, trim, and other surfaces with a mild detergent and water.
- Remove grease and oil with a standard nonflammable cleaning fluid.
- □ This product has been coated with an industrial UV-resistant power coating for a durable and long lasting finish.

 To help protect the coating, do not allow harsh chemicals to remain on the surface for extended periods of time.

Replacement Parts

For assistance with replacement parts please call 1-888-HD-HUSKY.



Per Top Locker Cabinet

Part	Part#	Description	Quantity
Α	xxxxxxxxx	Magnetic Badge	1
В	xxxxxxxxx	Kwikset Smartkey® Lock	1
С	xxxxxxxxx	Кеу	2
D	xxxxxxxxx	Rubber Grommet	2
E	xxxxxxxxx	Gas Strut	2
F	xxxxxxxxx	Side Handle (Total)	2
G	xxxxxxxxx	Side Handle Bolt	4
Н	xxxxxxxxx	EVA Spacer	2
ı	xxxxxxxxx	Hexagon head flat bolt (M8*60mm)	4
J	xxxxxxxxx	Washer	4
K	xxxxxxxxx	Aluminum Edge Guard	2
L	xxxxxxxxx	Plastic Plug (M6)	8
М	xxxxxxxxx	Plastic Plug (ø15mm)	4





Questions, problems, missing parts? Before returning to the store call
Husky Customer Service
8 a.m. - 7 p.m., EST, Monday-Friday
9 a.m. - 6 p.m., EST, Saturday

1-888-HD-HUSKY

HUSKYTOOLS.COM

Retain this manual for future use.