Bremen



Cabinet Assemble Illustration


If you receive the products in damage or missing parts, please call 678-390-2961 or email to cs@bremencabinetry.com. We will send you the parts you need.

You can find assemble videos and photos on our website. If you need further assistant, don't hesitate to contact us.


www.BremenCabinetry.com

Base Cabinet


B09,B12,B15,B18,B21,B24,B30,B36,BBC36-42 SB30,SB33,SB36,V2421,V2721,V3021,V3621 (Without Drawer Box)




Insert the side panel from end of face frame




Attach bottom panel with face frame and side panel



3 Attach back panel then screw up



Fix drawer box on the drawer front and adjust the cover-space





Fix door onto the frame and adjust the cover-space,put on adjustable shelf

QTY	HARDWARE	
2 or 4	1 1/4"Soft Close Hinge	P
2 or 4	3/4™Round Head Screw	=
4 or 8	5/8"Flat Head Screw	I
6 or 8	Bumper	0
8	Cleat	8
40	1/2*Flat Head Screw	-
4	1"Flat Head Screw	
4	Shelf Clip	
4	Plastic Triangle	7
. 1	Silder	


Base Cabinet

DB12-3,DB15-3,DB18-3,DB21-3,DB24-3,DB30-3,DB36-3 VDB12-3,VDB15-3,VDB18-3,VDB21-3,VDB24-3







2 Attach bottom panel with face frame and side panel



Attach back panel then screw up




Fix drawer box on the drawer front and adjust the cover-space




QTY	HARDWARE	
12	Bumper	0
8	Cleat	8
40	1/2"Flat Head Screw	
4	1"Flat Head Screw	ezith.
4	Plastic Triangle	0
3	Slider	
		1.0
·		

Wall Cabinet


W3612,W3615,W3618,W3621 W3624,W361224,W361524, W361824,W362424 W3630,W3636,W3642 W3630GD,W3636GD,W3642GD




 Insert the side panel from end of face frame




② Attach top and bottom panel with face frame and side panel



Attach back panel then screw up



Fix doors onto the frame and adjust the cover-space




③ Put on the adjustable shelves

QTY	HARDWARE	
4 or 6	1 1/4"Soft Close Hinge	5
4 or 6	3/4"Round Head Screw	
8 or 12	5/8"Flat Head Screw	Ī
4	Bumper	Q
14	Cleat	8
56	1/2"Flat Head Screw	-
4	1"Flat Head Screw	- A
8 or 12	Shelf Clip	(60)


6 Hinge For 36"And42" High Wall Cabinet 12 Shelf Clips For 42" High Wall Cabinet

Wall Cabinet


WDC2430,WDC2436,WDC2442, DCW2430GD,DCW2436GD,DCW2442GD




Insert the side panel from end of face frame




2 Attach top and bottom panel with face frame and side panel



3 Attach back panel then screw up



Fix door onto the frame and adjust the cover-space




③ Put on the adjustable shelves

QTY	HARDWARE	
2 or 3	3/8"Soft Close Hinge	Þ
2 or 3	3/4*Round Head Screw)
4 or 6	5/8"Flat Head Screw	Ī
2	Bumper	0
22	Cleat	8
88	1/2"Flat Head Screw	A
4	1"Flat Head Screw	- A
8 or 12	Shelf Clip	(60)


3 Hinge For 36"And42" High Wall Cabinet 12 Shelf Clips For 42" High Wall Cabinet

Wall Cabinet


W0930,W1230,W1530,W1830,W2130 W0936,W1236,W1536,W1836,W2136 W0942,W1242,W1542,W1842,W2142 WBC2730,WBC2736,WBC2742 W1830GD,W2130GD,W1836GD W2136GD,W1842GD,W2143GD




 Insert the side panel from end of face frame




② Attach top and bottom panel with face frame and side panel



3 Attach back panel then screw up



Fix door onto the frame and adjust the cover-space



③ Put on the adjustable shelves

QTY	HARDWARE	
2 or 3	1 1/4"Soft Close Hinge	Þ
2 or 3	3/4"Round Head Screw)
4 or 6	5/8"Flat Head Screw	Ī
2	Bumper	Q
10	Cleat	8
40	1/2"Flat Head Screw	A
4	1"Flat Head Screw	carril.
8 or 12	Shelf Clip	(600)

3 Hinge For 36"And42" High Wall Cabinet 12 Shelf Clips For 42" High Wall Cabinet