





Item # 1003 005 279

USE AND CARE GUIDE

TUB DRAIN WRENCH



- Removes Most Tub, Shower, and Sink Strainers or Closet Spuds
- Durable Die-cast Aluminum

Read All Instructions Carefully Before Using:

1. Select appropriate end of wrench and insert into drain
2. With use of either adjustable wrench or heavy-duty screwdriver, turn wrench counter clockwise to remove drain

Tools Needed for Use:

Screwdriver or Adjustable Wrench

Warranty

If your Husky hand tool ever fails, bring it back and we will replace it Free. For details on this full warranty, visit your nearby store or call 1-888-HD-HUSKY.