




Item # 1003 002 606

USE AND CARE GUIDE

INTERNAL PIPE WRENCH SET



- For 3/8 in, 1/2 in, 3/4 in Pipe Nipples
- For Removing Frozen or Broken Pipe Nipples
- Expandable Knurled Cams for Easy Internal Grip

Read All Instructions Carefully Before Using:

NOTE: Turn off water supply before beginning procedure

1. Align cam to fit inside pipe nipple
2. To unscrew nipple from fitting, rotate internal pipe wrench counter-clockwise using a wrench
3. Clean fitting threads, connect new nipple or pipe as needed Tool Needed for Use: Adjustable Wrench

- Para boquillas de tubería de 3/8, 1/2 y 3/4 plg
- Para quitar boquillas de tubería rotas o congeladas
- Levas estriadas expandibles para un fácil agarre interno

Lee con cuidado todas las instrucciones antes de usar:

NOTA: CIERRA EL SUMINISTRO DE AGUA ANTES DE COMENZAR EL PROCEDIMIENTO

1. Alinea la leva para que encaje dentro de la boquilla de tubería
2. Para desenroscar la boquilla del acoplamiento, gira la llave para tubería interna hacia la izquierda usando una llave
3. Limpia las rosas del acoplamiento, conecta la boquilla o tubería nueva, según sea necesario

Warranty

If your Husky hand tool ever fails, bring it back and we will replace it Free. For details on this full warranty, visit your nearby store or call 1-888-HD-HUSKY.