




SKU# 1006 782 185  
Model# SMAHD080BR-WDG

## USE AND CARE GUIDE

### ROUND LED LOW BAY LIGHT WITH UP LIGHT



Questions, problems, missing parts? Before returning to the store,  
call Commercial Electric Customer Service  
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

#### THANK YOU

We appreciate the trust and confidence you have placed in Commercial Electric through the purchase of this Round LED High Bay. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Commercial Electric!

## Table of Contents

Table of Contents	2	Pre-Installation	3
Safety Information	2	Tools Required	3
Warranty	3	Hardware Included	3
Electrical Ratings	3	Installation	4-6

## Safety Information

### For your safety, always remember to:

- Turn off the power supply at the fuse or circuit breaker box before you install the fixture.
- Ground the fixture to avoid potential electric shocks and to ensure reliable starting.
- Double-check all connections to be sure they are tight and correct.
- Wear rubber soled shoes and work on a sturdy wooden ladder.
- Account for small parts and destroy packing material, as these may be hazardous to children.

This fixture is designed for use in a circuit protected by a fuse or circuit breaker. It is also designed to be installed in accordance with local electrical codes. If you are unsure about your wiring, consult a qualified electrician or local electrical inspector, and check your local electrical code.

**WARNING: RISK OF SHOCK.** House electric current can cause painful shock or serious injury unless handled properly.

**WARNING: THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.**

**WARNING: MIN 75°C SUPPLY CONDUCTORS.**

**CAUTION:** Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

**NOTICE:** All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## FCC STATEMENT


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the manufacture could void the user's authority to operate the equipment.


## Installation

### 1 Disassembling the package and take the fixture out



### 2 Attaching the Hook to the fixture


- Clockwise rotate the Hook (A) into the threaded hole of the drive box.
- Lock the screw (B) on the side of the drive box to prevent the hook from loosening.



## Installation (continued)


### 3 Choosing the up light

- According to your needs, choose whether to use the up light. The ON-OFF switch is on the back of fixture.



### 4 Installing fixture to the ceiling


- Hang the chain (not included) to the ceiling.
- Fit the hook (A) to the lower end of chain, then lock the hook with screw (D).



## Installation (continued)

### 5 Connecting the supply wires

- Loosen the wire and pull it into the junction box in the ceiling.
- Connect the three supply wires (black-hot,white-neutral,green-ground) coming from top of low bay fixture to the electrical power supply same color wires. Secure wires using wire nuts (C).



### 6 Turning on the light

- Power on and turn on the light.

## Warranty

### LIMITED WARRANTY


This product is warranted to be free from defects in workmanship and materials for up to 5 years from date of purchase. If it fails to do so, please contact the Customer Service Team at 1-877-527-0313 or visit www.HomeDepot.com.

## Electrical Ratings

Volts (V)	Frequency (Hz)	Watts (W)	Current (mA)	Color Temperature (K)	Lumen (lm)	Life (Hrs)
120-277	50/60	90	930	5000	9000	50000


## Pre-Installation

### TOOLS REQUIRED



### HARDWARE INCLUDED

**NOTE:** Hardware not shown to actual size.



Part	Description	Quantity
A	Hook	1
B	Screw(M5×14)	1
C	Wire nut	3
D	Screw (M4×28)	1



Questions, problems, missing parts? Before returning to the store,  
call Commercial Electric Customer Service  
8 a.m. - 7 p.m., EST, Monday - Friday  
9 a.m. - 6 p.m., EST, Saturday  
1-877-527-0313  
HOMEDEPOT.CA  
Retain this manual for future use.

FCC compliance information is listed as below:  
Responsible party: Leedarsen America, Inc.  
Responsible party address: 300 Technology Court SE Suite 100, Smyrna, GA 30082  
Telephone number: (678) 293-8382