



Installation Guide of Microwave Sensor

Sensor installation method 1


1. Use a screwdriver to remove the 4 fixing screws in the middle of the lamp(Fig 1);




2. Pass the waterproof connector through the radiator, place it on the back of the lamp, and place the sensor(Fig 2);




3. Secure the sensor by locking the screws (Fig 3) ;



4. Connect the power and sensor wires as shown in the figure(Fig 4);




5. Complete the installation and test the light(Fig 5).



Sensor installation method 2

1. Unscrew the sensor housing in the direction shown(Fig 6);



2. Screw the sensor into the bottom of the sensor to complete the installation (Fig 7); Lighting test.

