



Shower Door Installation Instructions



Reversible for a left or right door installation.

**Please do not return the product to the store.
Contact us with any questions.**

Model Specific Preparation





REQUIRED:


Verify threshold and wall with a level.

1/4"(6mm) Maximum out of plumb adjustment from top to bottom

Threshold must be level.



PACKAGE CONTENT



PACKAGE CONTENT








PART#	DESCRIPTION	QTY
A	Wall Jamb	2
B	Stationary Glass	1
C	Stationary Glass	1

PART#	DESCRIPTION	QTY
D	Stationary Glass	1
E	Support Rod	1
F	Decorative cover	2
G	Wall Jamb	2

NOTE

Inspect all parts for missing prior to installation!
Contact us for any part missing.








PACKAGE CONTENT



HARDWARE CONTENT




Additional spare parts are included.



Inspect all parts for missing prior to installation!
Contact us for any part missing.


TOOLS REQUIRED

Drill Bits




Ø1/8" & Ø1/4" (3&6mm) dia.
HSS


Phillips screw driver




Electric hand drill




Level




Silicone gun




Measuring Tape




Soft Head Hammer




Marking Pencil



Utility Knife




Sealant



MASONRY DRILL
BIT FOR TILE
Ø6mm




Safety Glasses




Glove




Carpenter's Squarer




Masking or painter's
tape




Hack Saw



Metal File



Glass suction
Handle



SAFETY INFORMATION


CAUTION

Please carefully read the following important safety information before handling or installing this shower door . There is a risk of serious injury while handling this product.


To minimize these risks, please note:

- Always wear safety glasses and gloves while handling.
- Always follow the installation instructions.
- Inspect glass for damage before installation.
- Extreme caution should be taken while handling the glass during installation as the tempered glass may shatter if in contact with a hard surface.
- Do not cut or modify the tempered glass as it will shatter if cut.
- Carefully remove product from packaging and keep packaging until installation is complete.
- Inspect all parts for damage or missing; if there is damage or part missing to the unit prior to installation, please contact customer service at the number provided in this guide.
- Cover the drain with tape to prevent the loss of small parts.
- The shower base and finished walls should be installed before beginning the shower door installation.
- During the installation, protect the shower floor with a drop cloth to avoid damage.
- This product should be installed by two people who are familiar with construction requirements. Professional installation is recommended!
- Keep this installation manual for future reference.

NOTE: Two people should perform this installaton.



Model Dimensions



configuration dimensions:

A Product Height	B Mod I width	Installation width
72"	34"	34"
72"	46"	46"

NOTE

This model is reversible for right or left-hand door installation. The left-hand door installation is shown throughout this manual. For the right-hand door installation, simply begin on the opposite wall and reverse the orientation of the installation steps shown.


1

Determine your step in from the edge of tray and plumb your **Wall Jambs(A)**.

NOTE


1. Determine your starting point from the edge of tray ($\frac{3}{8}$ " (10mm) is recommended) and mark the position as Fig.a .

2.After the **Wall Jamb(A)** is vertical, mark the screw holes with a pencil as Fig.b .



The mated side is facing up



Note: mark as the outline of profile hole



2 Drill screw holes for **Wall Jamb(A)** and insert in the **Wall Anchor(aa)**.

NOTE

1. Drill holes with $\phi 6\text{mm}(1/4")$ drill bit as Fig.a.
2. Insert the **Wall Anchors(aa)** as Fig.b.




NOTE

- If a Stud is present behind the wall:
drill $\phi 1/8"$ (3mm) pilot holes into the stud and use the ST4.0x30mm **Screws(bb)**
OR
- If NO Stud is present behind the wall:
drill $\phi 1/4"$ (6mm) holes and insert the **Wall Anchors(aa)** and use the ST4.0x30mm **Screws(bb)**.

3 Install **Wall Jamb(A)**.

NOTE


1. Fix **Wall Jamb(A)** with **Screw(bb)** as Fig.a .



4 Install **Decorative cover(F)**.

NOTE


1. Install **Decorative cover(F)** as Fig.a .



5 Install Wall Jambs(A).

NOTE

1. Install the **Wall Jamb(A)** on the **Decorative cover(F)** as Fig.a .
2. After the **Wall Jamb(A)** is vertical, mark the screw holes with a pencil as Fig.b .



6 Drill screw holes for **Wall Jamb(A)** and insert in the **Wall Anchor(aa)**.

NOTE

1. Drill holes with $\phi 6\text{mm}(1/4")$ drill bit as Fig.a.
2. Insert the **Wall Anchors(aa)** as Fig.b.

Fig.a (1/4")
 $\phi 6\text{mm}$






Fig.b




NOTE

- If a Stud is present behind the wall:
drill $\phi 1/8"$ (3mm) pilot holes into the stud and use the ST4.0x30mm **Screws(bb)**
OR
- If NO Stud is present behind the wall:
drill $\phi 1/4"$ (6mm) holes and insert the **Wall Anchors(aa)** and use the ST4.0x30mm **Screws(bb)**.

7 Install Wall Jamb(A).

NOTE 1. Fix **Wall Jamb(A)** with **Screw(bb)** as Fig.a and Fig.b .





8-1 Install Assembling the **Stationary Glass(D)**

NOTE

1. Install the **Stationary Glass(D)** in the **Wall Jamb(A)** as Fig.a.

Insert the **Stationary Glass**
into the **Wall Jamb** to the end



CAUTION: Do not put glass
directly on the ground




Note: The shower door can be
installed left or right, according
to the need to determine the
installation direction.

8-2 Install Assembling the **Stationary Glass(C)**

NOTE

- 1.Install the **Stationary Glass(C)** in the **Wall Jamb(A)** as Fig.a and Fig.b.
- 2.Install the **Stationary Glass (C)** into the **Stationary Glass (D)** as Fig.c and Fig.d.




Note: The shower door can be installed left or right, according to the need to determine the installation direction.

8-3 Install the **Stationary Glass(B)**

NOTE

1. Install the **Stationary Glass(B)** in the **Wall Jamb(A)** as Fig.a and Fig.b.
2. Install the **Stationary Glass (B)** into the **Stationary Glass (C)** as Fig.c and Fig.d.




Note: The shower door can be installed left or right, according to the need to determine the installation direction.

9

Install Wall Jamb(G) and Decorative cover(F)

NOTE

1. Install the **Wall Jamb(G)** on the **Stationary Glass** as Fig.a .
- 2.Install the **Decorative cover(F)** on the **Wall Jamb(G)** as Fig.b.
3. Install the **Wall Jamb(G)** on the **Stationary Glass** as Fig.c and Fig.d



CAUTION: Do not put glass directly on the ground






Note: The shower door can be installed left or right, according to the need to determine the installation direction.

10 Fix Stationary Glass (B&C&D).


NOTE

1. Use a drill bit to drill 4 holes on the inside as Fig.a .
2. Install **Screws(dd)** and screw cover cap **Washers(ee)** as Fig.b .
3. Install **Screw caps(cc)** as Fig.c .

⚠ Take care not to drill into the glass



⚠ Take care not to drill into the glass



X4



ee X4
dd X4

cc X4


11 Fix Stationary Glass(B&C&D)

NOTE

1. Drill 8 holes on the inside of the **Wall Jambs(A&G)** with 1/8"(3mm) drill bit as Fig.a .
2. Install **Screws(dd)** and screw cover cap **Washers(ee)** as Fig.b .
3. Install **Screw caps(cc)** as Fig.c .



! Take care not to drill into the glass




12


Use a miter saw or hacksaw to cut the **Support Rod(E)**

NOTE

1. Measure the width of the shower room X, the size of the **Support Rod (E)** X minus 10(13/32")
2. Note: The maximum width of the Support Rod(E) installation is 1000mm(39 3/8")



Note: The side of the hole near the edge cannot be cut



Support Rod

13 Install the **Support Rod(E)** to the **Stationary Glass(B&C&D))**

NOTE

- 1.Flush **Wall Jamb(G)** with **Auxiliary drilling card(gg)** as Fig.a
2. Mark the holes with a pencil as Fig.b










Fig.a



Note: mark as the outline of profile hole

Fig.b




Take care not to drill into the glass

14 Install the **Support Rod(E)** to the **Stationary Glass(B&C&D))**

NOTE


1.Remove the **Support Rod(E)** connector as**Fig.aandFig.b**



15 Install the **Support Rod(E)** to the **Stationary Glass(B&C&D))**

NOTE



1. Fix the support rod connector to the wall jamb (G) with screws (bb) as Fig.a
2. Insert the **Support Rod(E)** into the support rod connector as Fig. b
3. Once the **Support Rod(E)** bars are parallel, mark the **Support Rod(E)** bars with a pencil



16 Install the **Support Rod(E)** to the **Stationary Glass(B&C&D)**

NOTE

1. Fix the support rod connector to the wall jamb (G) with screws (bb) as Fig.a
2. Insert the **Support Rod(E)** into the support rod connector as Fig. b
3. Once the **Support Rod(E)** bars are parallel, mark the **Support Rod(E)** bars with a pencil



NOTE

- If a Stud is present behind the wall:
drill $\phi 1/8''$ (3mm) pilot holes into the stud and use the ST4.0x30mm **Screws(ff)**
OR
- If NO Stud is present behind the wall:
drill $\phi 1/4''$ (6mm) holes and insert the **Wall Anchors(aa)**
and use the ST4.0x30mm **Screws(ff)**.


17 Install the **Support Rod(E)** to the **Stationary Glass(B&C&D)**

NOTE

1.Insert the **Support Rod(E)** into the **Support Rod(E)** connector and fix it with screws as Fig.a and Fig.b

2.Fix the **Support Rod(E)** connector with **screws (ff)** as Fig.c .

3.Insert the **Support Rod(E)** into the **Support Rod(E)** connector and fix it with screws as Fig.d and Fig.e .





18 SEALING

NOTE The surfaces need to be clean and free of debris before applying silicone.

NOTE Apply a good quality silicone sealant along the **Wall Jamb(A)** and Bottom **Stationary Glass(B)**.



Allow 24 hours for the silicone to cure before using the shower.



! Apply Silicone Sealant, (not supplied).

! Sealant needs to be applied inside and out