


## Shower Door Installation Instructions




**Reversible For a Left or Right Door**


**Please Do Not Return the Product to the Store.  
Contact us with any questions.**

## Model Specific Preparation

 **REQUIRED:**



PACKAGE CONTENT




PACKAGE CONTENT

PART#	DESCRIPTION	QTY	PART#	DESCRIPTION	QTY
A	Bottom Gasket	2	H	Single side strip	1
B	Pivoting Door panel	1	I	Alu. Threshold	1
C	Wall Jamb	1	J	U channel	1
D	Top Cover Cap	1	K	Bottom bracket	1
E	Handle	1	L	Stationary glass	1
F	Top Bar	1	M	Threshold Cap M1&M2	2
G	Magnetic strip	1	N	Threshold Cap N1&N2	2


NOTE

Inspect all parts for missing prior to installation!  
Contact us for any part missing.

## PACKAGE CONTENT




## HARDWARE CONTENT



**NOTE** Inspect all parts for missing prior to installation!  
Contact us for any part missing.


TOOLS REQUIRED

Drill Bits




3.2/6mm dia.  
HSS


Screw Driver




Drill




Level




Silicone




Measuring Tape




Soft Head  
Hammer




Pencil



Knife




Sealant



MASONRY DRILL  
BIT FOR TILE  
Ø6mm




Safety Glasses




Glove




Carpenter's Squarer




Masking or painter's  
tape



Hack Saw



Metal File



## SAFETY INFORMATION


### CAUTION

Please carefully read the following important safety information before handling or installing this shower. There is a risk of serious injury while handling this product.


To minimize these risks, please note:

- Always wear safety glasses and gloves while handling.
- Always follow the installation instructions.
- Inspect glass for damage before installation.
- Extreme caution should be taken while handling the glass during installation as the tempered glass may shatter if in contact with a hard surface.
- Do not cut or modify the tempered glass as it will shatter if cut.
- Carefully remove product from packaging and keep packaging until installation is complete.
- Inspect all parts for damage or missing; if there is damage or part missing to the unit prior to installation, please contact customer service at the number provided in this guide.
- Cover the drain with tape to prevent the loss of small parts.
- The shower base and finished walls should be installed before beginning the shower door installation.
- During the installation, protect the shower floor with a drop cloth to avoid damage.
- This product should be installed by two people who are familiar with construction requirements. Professional installation is recommended!
- Keep this installation manual for future reference.

**NOTE:** Two people should perform this installation.



Model Dimensions



configuration dimensions:

A Product Height	B Model width	Installation width
72"	60"	60" ~60 9/16"



**1-1**

**Wall Jamb (C) Installation**

NOTE

Confirm the Wall jamb is plumb with a level before marking the location of the holes for drilling.






Fig 1






NOTE

Wall jamb (C) must be in line with the Center of Threshold.



## 1-2

### Wall Jamb (C) Installation



NOTE


- If a Stud is present behind the wall:  
drill a  $\varnothing 3/16"$  (4mm) hole up to the stud,  
drill an  $\varnothing 1/8"$  (3mm) pilot hole into the stud and  
use the **ST4.0 x 30mm Pan Head Screws (bb)**  
OR
- If No Stud is present behind the wall:  
drill a  $\varnothing 1/4"$  (6mm) hole and insert the **Wall Anchors (aa)**  
and use the **ST4.0 x 30mm Pan Head Screws (bb)**.

## 2

## Pivoting Door panel (B) Installation

**NOTE**

The Door panel Profiles can be adjusted up to  $\frac{3}{8}$ " within the **Wall Jamb (C)** for overall width or to correct for out-of-plumb conditions within the model size. Screw them together after making final adjustments.



Pivoting panel can rotate 90 degrees in either direction allowing it to be right hand or left hand.







Fig 3

**NOTE**


Place **wood shim(hh)** onto the threshold to provide proper spacing beneath the door glass and squareness.

Make any final adjustments to the door so that it is level and plumb in the opening.




## 3 Magnetic strip (G) Installation

- 1、 Mark a line on the threshold base on the handle side See Fig. 4 for details.
- 2、 Press the **Magnetic Strip (G)** on the vertical edge of the **Glass Door (B)**.



## 4 Stationary glass panel (L) Assembly Installation

Attach the **Bottom bracket (K)** to the **Stationary Glass (L)** using two vinyl hinge gasket per side.



## 4<sub>-1</sub>

### Stationary Glass (L) Installation

1、 Install the **U channel (J)** onto the **Stationary Glass (L)** in the shown location. Place the door open of the **Stationary Glass(L)** on threshold opposite of **Glass Door(B)**. Adjust the **Stationary Glass(L)** and **U channel (J)** against the wall to compensate for any out of plumb conditions ensuring that the **Stationary Glass(L)** is level vertically and **U channel (J)** is flush with the wall.

See Fig. 6 for details

NOTE




Fig 6

Install the **Magnetic Strip (G)** on the vertical edge of the **Stationary Glass (L)**. Align the **Stationary Glass(L)** with the threshold door mark and then close the door. Adjust the position of the **Stationary Glass(L)** so that the **Magnetic Strip(G)** makes tight contact to the **Glass Door(B)** from top to bottom.

NOTE: The top of the **Stationary Glass(L)** must be level with the **Glass Door(B)**.

Mark the **U channel (J)** at the top horizontal glass edge.

Mark the position of the bracket along the inside edge of **Stationary Glass(L)** on the threshold base.

See Fig. 7 for details

NOTE





Fig 7

## 5

### Fasten the **Pivoting Door panel (B)**

**NOTE**


After final adjustments, drill  $\varnothing 1/8"$  holes in the **Wall Jamb (C)**.  
Drill only through the first layer of the Door panel Profile and install the **ST4.0x10mm Pan Head Screws (dd)** using the **Decorative Covers and Washers (cc)**



**Fig 8**

**NOTE**

Include the washers when installing the ST4.0x10mm **Pan Head Screws (dd)** and **Decorative Caps (cc)**.



## 6

### U channel (J) Installation

- 1、 Remove the **U channel (J)** from the **Stationary Glass (L)** and set the **Stationary Glass(L)** aside; Place the **U channel (J)** align vertically with the mark on the wall.
- 2、 Mark the drill holes on the wall through the predrilled holes in the **U channel (J)**.
- 3、 Drill holes in the wall using  $\varnothing 1/4"$  drill bit and insert the  $\varnothing 1/4"$  **Wall Anchors (aa)**.
- 4、 Apply silicone along the bottom surface and around the holes of the **U channel (J)** .
- 5、 Fasten the **U channel (J)** to the wall with the **Screw ST4x30 (ee)**.

See Fig. 9 for details.






Fig 9





**7****Bottom bracket (K) installed on Acrylic bathtub**

Drill one Ø1/8" (3.2mm) hole. Attach the **Bottom bracket (K)** using **ST4 x 30 Screws (ee)** as Fig.10.1、 Fig.10.2.




Fig.10

If the installation surface is acrylic **NOTE**

**7-1****Bottom bracket (K) installed on stone bathtub**

Drill one Ø1/4" (6mm) hole and insert the **Wall Anchor (aa)**. Attach the **Bottom bracket (K)** using **ST4 x 30 Screws (ee)** as Fig.11.1、 Fig.11.2、 Fig.11.3.







Fig.11


If the installation surface is stone **NOTE**





# 8

## Stationary Glass (L) Assembly Installation



- 1、 Apply silicone along the inside surface and around the holes of the **U channel (J)**;
- 2、 Insert the **Stationary Glass (L)** into **U channel (J)**;
- 3、 NOTE: The top of the **Stationary Glass (L)** must be level with the **Glass Door(B)**.
- 4、 Insert the **Single side strip (H)** into **U channel (J)**;
- 5、 Attach the **Stationary Glass (L)** as Fig.12.5 ;

If needed , adjust the position of the **Stationary Glass(H)** so that the **Magnetic Strip(G)** makes tight contact to the **Glass Door(B)** from top to bottom.

See Fig. 12 for details.






Fig.12

## 9

### Top Bar (F) Installation

#### NOTE

1. Use a level and position the **Top Bar (F)** onto the **Stationary Glass (L)** as shown and mark the position on the wall as Fig.a
2. Remove the **Top Bar (F)** and mark the holes for drilling as Fig.b;
3. Drill one  $\text{Ø}5/16"$  (8mm) hole and insert the **Wall Anchor (gg)**. Attach the **Top Bar (D)** using **ST5 x 30 Screws (ff)** as Fig.c、 Fig.d and Fig.e;
4. Position the **Top Bar (F)** onto the **Stationary Glass (L)** and onto the wall as Fig.f




Fig 13

#### Inside View




Fig.a




Fig.b




Fig.c




Fig.d




Fig.e




Fig.f

# 10 Handle (E) Installation




Fig 14

NOTE

Remove the **wood shim(hh)** and open the door.

11

## Top Cover Cap (D) & Bottom Gasket (A) Installation














Fig 15

**NOTE** "X" is from pivot profile to magnetic seal on the door.

# 12

## Alu.Threshold (I) Installation



1. **Threshold Caps (M&N)** are divided into left and right two types, Select according to the installation method **Threshold Caps (M&N)** as Fig 1;
2. Measure "X" and cut the **Alu. Threshold(I)** same length as "(X+1 9/16inch)" as Fig.2 ; Fig.3 and Fig.4;
3. Apply silicone into the groove along the entire length of the **Alu. Threshold(I)** as Fig 5;
4. Combine the **Alu. Threshold(I)** and **Threshold Caps (M&N)** as Fig.6 .



The Thicker curved lip of the dam strip is intended to face toward the outside of the shower to ensure the flow of water is redirected towards the drain.




## 13 SEALING

**NOTE** The surfaces need to be clean and free of debris before applying silicone.

**NOTE** Ensure that the Shower door closes tightly and opens smoothly.  
**Apply a good quality silicone sealant along the wall Jamb(C) & Water seal (I) & Stationary Glass (L) and U channel (J) .**

**!** Allow 24 hours for the silicone to cure before using the shower.



**!** Apply Silicone Sealant,(not supplied).





Fig 17