


# Installation

## 1 Cleaning the air hose

- A 1/2" air hose is required, with a maximum length of 25 ft.
- Clean the air hose of accumulated dust and moisture before connecting it to the air supply.



**NOTE:** If a longer air hose is required, connect a 3/4" air hose to the 1/2" air hose to ensure the tool has the necessary air supply.



## 2 Connecting to the air supply

- Always use clean dry air. Excessive moisture and dirt will greatly reduce the life of any air motor. We recommend the installation of an in-line filter-regulator-lubricator as close to the tool as possible.
- Ensure all hoses and fittings are the correct size and secured tightly.

**Recommended Air Line Set-Up**

| Part | Description        |
|------|--------------------|
| A    | 3/4" Impact Wrench |
| B    | Quick Plug         |
| C    | Quick Coupler      |
| D    | Air Hose           |
| E    | In-line Regulator  |
| F    | In-line Lubricator |
| G    | In-line Filter     |
| H    | Air Compressor     |

