


These installation guidelines are for use with typical or standard applications. It is always recommended to seek advice from a licensed professional, and to check with your local building inspector or building permit office for approvals and possible variations that may apply.

STAPLE ATTACHMENT


- For regular (not bullnose) archway corner beads, drywall does not need to be set back
- For doors, windows or special lengths, cut the bead to length and dry fit
 - a. Prevent overlap of the mud flanges by snipping back
 - b. Dry fit the bead
- With 1/2" crown staples staple the solid mud flange every 6-10" and each flange segment on the notched mud flange.
- No primer is needed. Finish as usual.
- For cold weather winter applications, please refer to the installation recommendations in the Gypsum Association GA-220-2020.



- Archway Cornerbead is slotted (kerfed) to fit smoothly around a curved surface.

SPRAY ADHESIVE

- For regular (not bullnose) archway corner beads, drywall does not need to be set back.
- For doors, windows or special lengths, cut the bead to length and dry fit.
 - a. Prevent overlap of the mud flanges by snipping back.
 - b. Dry fit the bead.
- Put a coat of spray adhesive on the back of the bead and then on the drywall per [the spray adhesive] manufactures instructions.
- The rate at which the adhesive dries varies depending on heat and humidity. Test in your conditions.
- Use handle of your taping knife or installation tool to apply pressure along both mud flanges. Bond strength is greatly enhanced with this crucial step.
- No primer is needed. Finish as usual.
- For cold weather winter applications, please refer to the installation recommendations in the Gypsum Association GA-220-2020.



- "L" Trim is used where drywall abuts suspended ceilings, beams, plaster, masonry and concrete walls.
- "J" Trim is used to finish rough drywall panel ends at window and door openings.