


Richelieu

2019

Accuride



Coulisse pour clavier d'ordinateur 14"
Keyboard slide 14"

GENERAL INSTRUCTIONS

Drawer member

Step 1: Separate slide members by depressing the lever release.

Step 2: Locate the screw holes on drawer 1-5/8" (min.) below the underside of the desk top of bracket at its lowest position.

NOTE: Mounting bracket adjusts vertically in 7/16" increments. (Figure 2)

Step 3: Position the front of the slide member 1/8" behind the drawer front. Install drawer member to drawer through vertical mounting slots. Secure with #8 pan head screws. (Figure 1)

Cabinet member

Step 1: Attach brackets to slide at desired height and position (inboard /outboard) using self-taping screws. Cabinet member to be mounted parallel to drawer sides.

Step 2: Position slide so the front of the cabinet member is 1/8" behind the drawer front when the drawer is in the closed position.

Step 3: Locate screw holes for mounting brackets on the underside of desk top (or equivalent mounting surface). See column "A" on chart for this dimension.

A. FOR BRACKETS FACING OUT

Use the width of the drawer plus 2-1/32" for bracket screw hole centers. (Figure 2)

B. FOR BRACKETS FACING IN

Use the width of the drawer minus 1/8" for bracket screw hole centers. (Figure 3)


NOTE: Tighten screws on one side, then open and close (cycle) drawer a few times to be certain the slides have self adjusted to a parallel movement and are moving freely. Tighten screws on the other side of the drawer.

Step 4: Adjust height of drawer and install remaining screws in moving member.

Richelieu

2019

Accuride



UCT20199014

Coulisse pour clavier d'ordinateur 14"
Keyboard slide 14"

FIGURE 1




FIGURE 2




FIGURE 3




FIGURE 4

